

※1バッテリーを2個使用

<b>Bel Air</b>		<b>Camaro</b>	
1981-80	V6 3.8L	1981-74	V8 5.0L Optional
1971-76	V8 5.7L	1981-70	V8 5.7L Optional
1980-77	V8 5.0L	1981	V6 3.8L Optional
1980	V8 4.4L	1980	V6 3.8L Optional
1979-77	L6 4.1L	1978-70	L6 4.1L Optional
1976-71	V8 6.6L	1975-70	V8 5.7L
1976-71	V8 7.4L	1973-70	V8 5.0L
1975-71	V8 5.7L	1972-70	V8 6.6L
1973-71	L6 4.1L Options	1969-67	L6 3.8L Optional
1970-69	V8 5.7L	1969-67	V8 5.0L
1969-66	V8 7.0L	1969-67	V8 5.4L
1969-65	V8 6.6L	1969-67	V8 5.7L
1969-62	V8 5.4L	1969-67	V8 6.6L
1965-61	V8 6.7L	1969	V8 7.0L
1963-55	L6 3.9L	1968-67	V8 7.0L
1963	V8 7.0L	1967	V8 4.7L
1962-57	V8 4.7L		
1961-58	V8 5.7L		
1957-55	V8 4.3L	<b>Caprice</b>	
1954-53	L6 3.9L w/12Volt	1996-95	V6 4.3L
		1996-95	V8 4.3L
<b>Biscayne</b>		<b>Caprice</b>	
1975-71	V8 7.4L	1985-84	V8 5.7L Diesel&Optional
1975-70	V8 5.7L	1985-83	V6 3.8L Optional
1975-70	V8 6.6L	1983	V8 5.7L Diesel
1973	L6 4.1L	1982-80	V8 5.7L Diesel
1970-68	L6 4.1L	1981	V6 3.8L Optional
1970	V8 7.4L	1980	V8 4.4L
1969-66	V8 7.0L	1979-77	V8 5.0L
1969-62	V8 5.4L	1978-76	V8 5.7L Gas Optional
1969-61	V8 6.6L	1976-71	V8 6.6L
1969	V8 5.7L	1976-70	V8 7.4L
1968	V8 5.0L	1975-71	V8 5.7L
1963-58	L6 3.9L	1970-66	V8 6.6L
1963-58	V8 7.0L	1969-66	V8 5.4L
1962-58	V8 4.7L	1969-66	V8 7.0L
1961-58	V8 5.7L	1967-66	V8 4.7L
		<b>Chevy II</b>	
<b>Beauville</b>		1968-67	L6 4.1L Optional
1957-55	L6 3.9L	1968-65	V8 5.4L Optional
1957-55	V8 4.3L	1968-64	L6 3.8L Optional
1957	V8 4.7L	1968-62	L4 2.5L Optional
<b>Bookwood</b>		1968	V8 5.0L Optional
1961-58	L6 3.9L	1968	V8 6.6L
1961-58	V8 4.7L	1966-62	L6 3.2L Optional
1961-58	V8 5.6L	1966-62	V8 4.7L Optional
1961	V8 6.7L		

※1バッテリーを2個使用

<b>Chevelle</b>		<b>Impala</b>	
1973-71	V8 5.0L	1965-64	L6 3.8L MFI or Optional
1973-71	V8 5.7L	1965-61	V8 6.7L
1973-70	V8 7.4L	1962-61	L6 3.9L
1972-71	V8 6.6L	1961-59	V8 5.7L
1970-69	V8 5.7L	1959	L6 3.9L
1970-68	V8 5.0L		
1970	V8 5.7L Optional		
1970	V8 6.6L	<b>Kingswood</b>	
1970	V8 6.6L Optional	1972-71	V8 5.7L
1969-66	V8 6.5L	1972-71	V8 6.6L
1968-64	V8 5.4L	1972	V8 7.4L
1966-64	L6 3.2L Optional	1970-69	V8 5.7L
		1970	V8 6.6L
		1970	V8 7.4L
<b>Chevette</b>		<b>Laguna</b>	
1986-83	L4 1.8L Diesel	1975-74	V8 6.6L
1982-81	L4 1.8L Diesel	1975-73	V8 5.7L
<b>Corvette</b>		1974-73	V8 7.4L
1980-78	V8 5.7L Optional	<b>Malibu</b>	
1975-69	V8 5.7L	1982-78	V6 3.8L Optional
1974-70	V8 7.4L	1981-76	V8 5.7L Gas,Optional
1969-66	V8 7.0L	1980-78	V8 5.0L Optional
1968-62	V8 5.4L	1979-78	V6 3.3L Optional
1961-57	V8 4.6L	1977-73	L6 4.1L Optional
1956-55	V8 4.3L	1976-74	V8 6.6L
<b>Del Ray</b>		1975-73	V8 5.7L
1958	L6 3.9L	1975-73	V8 7.4L
1958	V8 4.6L	1973	V8 5.0L
1958	V8 5.7L	1967-66	L6 3.8L
<b>Impala</b>		1967	L6 4.1L
2006	V6 3.9L	1967	V8 4.6L 5.4L 6.5L
1996-94	V8 5.7L	1966	L6 3.2L
1985-83	V6 3.8L Optional	1967	V8 4.6L 5.4L 6.5L
1985-83	V8 5.7L Diesel or Optional US	1965	L6 3.2L 3.8L
1982-80	V6 3.8L Optional	1965	V8 4.6L 5.4L
1982-80	V8 5.7L Optional Diesel	1964	L6 3.2L 3.8L
1979-77	L6 4.1L Optional	1964	V8 4.6L 5.4L
1976-71	V8 5.7L Gas	<b>Monte Carlo</b>	
1976-71	V8 6.6L	2006	V6 3.5L 3.9L
1976-70	V8 7.4L	1983-80	V6 3.8L Optional
1973-71	L6 4.1L Optional	1982-76	V8 5.0L Optional
1970-69	V8 5.7L	1982	V8 5.7L Optional Diesel
1970	V8 6.6L	1980-79	V8 4.4L
1969-66	V8 7.0L	1979-78	V6 3.3L Optional
1969-62	V8 5.4L	1979	V6 3.3L

※1バッテリーを2個使用

<b>Monte Carlo</b>		<b>Blazer</b>
1976-71	V8 6.6L	1978-76 V8 7.4L
1975-72	V8 5.7L	1975-71 V8 5.7L
1975-70	V8 7.4L	1975 V8 6.6L
1971	V8 5.7L	1973-71 V8 5.0L
1970	V8 5.7L 6.6L	1973 V8 7.4L
1979-78	V8 5.0L Optional	1970-69 V8 5.0L 5.7L
		1970 L6 4.8L
<b>Nova</b>		
1977-76	V8 5.0L Optional	<b>Blazer S10,T10</b>
1977-76	V8 5.7L Optional	1988-85 L4 2.5L Optional
1977-71	L6 4.1L Optional	1987-86 V6 2.8L Optional
1975-71	V8 5.7L	1985-83 V6 2.8L Optional
1975	V8 4.3L	1984-83 L4 1.9L 2.0L Optional
1973-71	V8 5.0L	<b>C&amp;K Pickup &amp; Suburbans</b>
1970	V8 5.0L 5.7L 6.5L 6.6L	2006-00 V8 5.3L 6.0L
1967-66	L4 2.5L	2006 V8 8.1L
1967-66	L6 3.2L	2005-01 V8 8.1L
1967-66	V8 4.6L 5.4L	2002-93 ※1 V8 6.5L Diesel
1967	L6 4.1L	2000-94 V8 5.7L
1966	L6 3.8L	2000-88 V8 7.4L
1965	L4 2.5L	1999-98 ※1 V8 6.5L Diesel
1965	L6 3.2L 3.8L	1999-94 V8 5.0L
1965	V8 4.6L 5.4L	1998-94 V6 4.3L
<b>Townsman</b>		1993-91 V6 4.3L
1972-71	V8 5.7L 6.6L	1993-91 V8 5.7L Auxiliary
1972	V8 7.4L	1993-91 V8 5.7L ex.Auxiliary
1970-69	V8 5.7L	1993-88 V8 5.0L
1970	V8 6.6L 7.4L	1992 V8 7.4L Auxiliary
<b>Astro Van</b>		1991-90 ※1 V8 6.2L Diesel
2005-94	V6 4.3L ex. SEO	1991 V8 5.7L
2005-94	V6 4.3L SEO or Optional	1990-88 V8 5.7L
1993-85	V6 4.3L	1989-88 ※1 V8 6.2L Diesel
<b>Avalanche (Includes 1500,2000)</b>		1986-83 V8 5.0L Optional
2006-02	V8 5.3L 8.1L	1986-83 ※1 V8 6.2L Diesel
2005-02	V8 5.3L 8.1L Optional	1986-83 V8 7.4L
<b>Blazer</b>		1986-82 V8 5.7L
2001-95	V6 4.3L	1986 L6 4.8L Optional
1994-91	V8 5.7L	1985 L6 4.8L Optional
1994	V8 6.5L Diesel	1982-81 L6 4.8L Optional
1991-90	V8 6.2L Diesel	1982-81 V8 5.0L 7.4L
1987-83	V8 5.0L	1982 ※1 V8 6.2L Diesel
1986-83	V8 6.2L Diesel	1981-78 V8 5.7L Diesel
1982	V8 6.2L Diesel	1981 V8 5.7L Gas

※1バッテリーを2個使用

C&k Pickup & Suburbans		El Camino	
1978-77	V8 6.6L Optional	1970-66	V8 6.5L
1978-77	V8 7.4L	1970	V8 5.7L 6.6L 7.4L
1976-73	V8 7.4L	1969-66	L6 3.8L
1976-71	V8 5.7L	1969	V8 5.7L
1976	V8 5.0L	1968-66	V8 5.4L
1975	V8 6.6L	1966-64	V8 6.4L
1973-71	V8 5.0L	1965-64	L6 3.8L
1972-71	V8 6.6L	1965	L6 3.2L
1971	L6 4.8L	1965	V8 5.4L
1970-69	V8 5.7L	1964	V8 5.4L
1970-68	V8 5.0L	1960-59	V8 4.6L 5.7L
1970-66	L6 4.1L		
1970-63	L6 4.8L		
1970	V8 6.6L		
1969-68	V8 6.5L		
1969	L6 3.8L		
1968-64	V8 5.4L		
1968	V8 6.5L		
1967-63	L6 3.8L		
1967-61	V8 4.6L		
1966-61	V8 4.6L		
1966	V8 4.6L 6.0L		
1965-64	V8 5.7L 6.7L		
1965	V8 4.6L 5.7L		
1964	V8 6.7		
1962-61	L6 3.9L 4.3L		
1962-61	V8 4.6L 5.7L		
1962	V8 5.4L 5.7L 6.7L		
1961	L6 4.3L		
Commercial Chassis			
1994-91	V8 5.7L		
1992	V6 4.3L		
El Camino			
1984-83	V8 5.7L Diesel	1996-88	V8 7.4L
1982	V6 3.8L Optional 5.0L	1996-87	V6 4.3L
1981-79	V8 4.4L	1996-87	V8 5.7L
1981	V6 3.8L Optional	1995-89	V8 5.0L
1979-78	V6 3.3L Optional	1993-92	※1 V8 6.2L Diesel
1975-74	V8 6.6L	1990-86	V8 6.2L Diesel
1975-71	V8 5.7L	1986	V8 5.7L Optional
1974-72	V8 7.4L	1985-84	V8 5.7L Gas
1973-71	V8 5.0L	1985-84	※1 V8 6.2L Diesel
1972-71	V8 6.6L	1984-83	L6 4.1L Optional
1970-68	V8 5.0L	1984-83	V8 5.7L Optional
1970-67	L6 4.1L	1980-75	V8 6.6L Optional
		1976-73	L6 4.8L Optional
		1973-71	V8 5.0L
		1972-71	L6 4.8L
		1972-71	V8 5.7L
		1971	L6 4.1L
		1970-68	V8 5.0L
		1970-67	L6 4.1L

※1バッテリーを2個使用

<b>G Series Van (Includes 1500,2500,3500)</b>	
1970	V8 5.7L
1969-67	L6 3.8L Optional
<b>R&amp;V Pickup &amp; Suburbans</b>	
1991-87	V8 5.7L Optional
1991-87	V8 6.2L Diesel
1991-87	V8 7.4L
1991	V8 5.7L Auxiliary
1988-87	L6 4.8L
1987	V8 5.0L Optional
<b>S10 Pickup</b>	
2004	V6 4.3L
1993-87	L4 2.5L Optional
1986-85	L4 2.5L
1986-84	V6 2.8L Optional
1985-83	L4 1.9L Optional
1985-83	L4 2.2L Diesel
1983-82	V6 2.8L Optional
<b>Silverado Pickup (Includes 1500,2500,3500)</b>	
2006-99	V6 4.3L
2006-99	V8 4.8L 5.3L 6.0L
2006-01	V8 8.1L
2006	V8 5.3L ex.Hybrid
2006	V8 6.0L 8.1L Gas
2005-99	V6 4.3L Optional
2005-99	V8 4.8L 5.3L 6.0L Optional
2005-01	V8 6.6L Diesel
2005-01	V8 8.1L Optional
2004	V8 6.6L Optional
<b>Tahoe</b>	
2006-00	V8 4.3L 5.3L
2000-95	V8 5.7L
1999-95	V8 6.5L Diesel