

※1バッテリーを2個使用

Fairlane (Includes 500)		Bronco	
1970	V8 7.0L	1977-69	V8 5.0L
1969-68	V8 7.0L	1972-67	L6 2.8L
1969-66	V8 6.4L	1968-66	V8 4.7L
1968-64	V8 4.7L		
1967	V8 7.0L	Courier	
1966-65	V8 7.0L	1979-72	L4 1.8L
1964-63	V8 4.3L	1978-77	L4 2.3L
1964	V8 6.4L		
1963-62	V8 3.6L	E Series Vans	
		1991-86	V8 5.0L Auxiliary
Mustang		1991-85	V8 5.8L Auxiliary
1973-72	V8 5.0L Optional	1991-85	V8 7.5L Auxiliary
1973-71	V8 5.8L	1981-80	L6 4.9L Optional
1973-69	L6 4.1L Optional	1980-75	V8 7.5L
1973-69	V8 5.8L Optional	1979	V8 5.0L
1971-68	V8 5.0L Optional	1975-69	V8 5.0L
1971-68	V8 7.0L	1975-69	V8 5.0L Optional
1970-65	L6 3.3L Optional	1974-67	L6 3.9L w/AT
1969-67	V8 6.4L Optional	1972	L6 4.9L
1968-65	V8 4.7L Optional	1971	L6 2.8L
		1970-68	L6 2.8L Optional
Rach Wagon		1964-62	L6 2.8L
1970	V8 5.0L 5.8L 6.4L	1964-61	L6 2.4L
1970	V8 7.0L 7.0L Optional		
		F & F350 SuperDuty 1Ton - Pickup	
Taurus		1959	L6 3.7L
1995-93	V6 3.2L SHO	1959	V8 4.8L
1995-89	V6 3.0L SHO		
		F100, F150 1/2Ton - Pickup	
Tunderbird		1979-78	V8 5.0L Optional
1979-78	V8 5.0L Optional	1979-78	V8 7.5L
1979-78	V8 5.8L Optional	1979-77	V8 5.8L Optional
1977	V8 6.6L	1979-77	V8 6.6L Optional
1976-74	V8 7.5L	1975-65	L6 4.9L Optional
1973-72	V8 7.5L	1977-73	V8 7.5L
1973-68	V8 7.0L	1977-70	V8 5.0L
1972	V8 6.6L	1976-75	L6 3.9L
1968	V8 6.4L	1976-68	V8 5.9L Optional 6.4L
1967-65	V8 6.4L	1974-65	L6 3.9L
1967-65	V8 7.0L	1969	V8 5.0L
1964-63	V8 7.0L Optional	1964-61	L6 3.7L
1964-61	V8 6.4L Optional	1964	V8 4.8L
1960-59	V8 7.0L Optional	1963	V8 4.8L
1960-58	V8 5.8L		
1957-56	V8 4.8L Optional	F250 Pickup (Includes SuperDuty)	
1957-56	V8 5.1L Optional	1986-83	※1 V8 6.9L Diesel
		1979-78	V8 7.5L

※1バッテリーを2個使用

F250 Pickup (Includes SuperDuty)		P400	
1979-78	V8 7.5L	1976-75	L6 4.9L
1979-77	V8 5.8L Optional	1976-75	V8 5.0L 6.6L
1979-77	V8 6.6L Optional		
1979-72	V8 5.0L Optional	P500	
1979-68	L6 4.9L Optional	1977-75	L6 4.9L
1977-73	V8 7.5L	1977-75	V8 5.0L 6.6L
1976-68	V8 5.9L Optional		
1974-65	L6 3.9L	Ranch Wagon	
1967-66	V8 5.8L Optional	1974-73	V8 7.5L
1967-65	L6 4.9L	1974-71	V8 6.6L
1964-63	V8 4.8L	1974-69	V8 5.8L
1964-61	L6 3.7L	1973-69	V8 7.0L
		1972-69	V8 5.0L
F350 Pickup (Includes SuperDuty)		1971-69	V8 7.0L Optional
1986-83	※1 V8 6.9L Diesel	1971-64	V8 6.4L
1982-80	V8 6.6L Auxiliary	1968-64	V8 4.7L
1980-72	V8 5.0L	1968	V8 7.0L
1979-78	V8 7.5L	1966	V8 7.0L
1979-77	V8 5.8L	1964	L6 3.7L
1979-68	L6 4.9L Optional	1964	V8 4.3L
1977-73	V8 7.5L	1959-58	L6 3.7L
1977	V8 6.6L	1959-58	V8 4.8L
1976-68	V8 5.9L 6.4L	1959-58	V8 5.8L
1974-65	L6 3.9L		
1967-66	V8 5.8L	Ranchero	
1967-65	L6 4.9L	1977-74	V8 5.7L
1966-64	V8 5.9L	1977-72	V8 6.6L
1965-60	V8 4.8L	1977-69	V8 5.8L Optional
1964-63	L6 3.7L	1974-69	V8 5.0L Optional
1964-61	L6 4.3L	1973-69	L6 4.1L Optional
1963-60	V8 5.4L	1973-68	V8 7.0L
		1969-67	V8 6.4L
F500		1968-66	L6 3.3L Optional
1977-75	V8 5.4L 5.9L 6.4L	1967-66	V8 4.7L
		1964	V8 4.3L
M-400, M-450			
1974	V8 5.9L 6.7L		
1973	V8 5.9L 6.4L		
P100, 350			
1976	V8 5.0L 6.6L		
1973-72	V8 6.4L		
1973	V8 5.9L		
1972-71	L6 3.9L		
1972	V8 5.0L		
1971	L4 4.2L		
1970	L6 3.9L		