

※1バッテリーを2個使用

1000, 1500, 2500 Series		Caballero
1965-64	L6 3.8L	1980-78 V8 5.0L Optional
1965-61	V6 5.0L	1979-78 V6 3.3L Optional
1962-61	L6 4.4L	1979-78 V8 5.7L Optional
C & K Pickup & Suburbans		Envoy
2002-94	※1 V8 6.5L Diesel	2006 L6 4.2L
2002-01	V8 8.1L	2006 V8 5.3L
2000-91	V8 5.7L	2005-03 V8 5.3L
2000-88	V8 7.4L	2005-02 L6 4.2L
1999-98	※1 V8 6.5L Diesel	G Series Vans
1999-98	V8 7.4L Optional	1996-94 ※1 V8 5.6L Diesel
1999-97	V8 5.7L Optional	1996-88 V8 7.4L
1999-88	V8 5.0L	1996-85 V6 4.3L
1998-91	V6 4.3L	1996-83 V8 5.7L
1990-88	V8 5.7L Optional	1995-87 V8 5.0L
1986-83	V8 5.7L Gas,Optional	1993-86 ※1 V8 6.2L Diesel
1986-83	※1 V8 6.2L Diesel	1986-83 V8 5.0L Optional
1986-82	V8 7.4L	1985-83 ※1 V8 6.2L Diesel
1986	V8 5.0L Optional	1984-83 L6 4.1L Optional
1985-83	L6 4.8L	1982-80 V8 5.7L
1985-81	V8 5.0L Optional	1982-77 V8 5.0L
1982	※1 V6 6.2L Diesel	1982 L6 4.1L Optional
1981-75	V8 7.4L	1980-75 V8 6.6L
1980-78	※1 V8 5.7L Diesel	1979 V8 7.4L
1980-77	V8 6.6L	1976-75 V8 7.4L
1976-75	V8 6.6L	1976-70 V8 5.7L
1974-73	V8 7.4	1974 L6 4.8L
1973-72	V8 5.0L	1973-70 V8 5.0L
1972-70	V8 6.6L	1970-67 L6 4.1L
1971-70	V8 5.7L	1969-68 V8 5.0L
1971-68	V8 5.0L	1969-64 L6 3.8L
1971-67	L6 4.8L	1967 V8 4.6L 5.4L
1971	L6 4.1L	1966 L6 3.2L
1970-66	L6 4.1L	Jimmy
1969-68	V8 6.5L	1994-92 V6 4.3L
1969-66	L6 3.8L	1991 ※1 V8 6.2L Diesel
1969	V8 5.7L	1990-87 V8 5.7L Auxiliary
1968-67	V8 5.4L	1990-87 ※1 V8 6.2L Diesel
1967-66	V8 5.0L	1986-82 ※1 V8 6.2L Diesel
1967	V8 4.6L	1981-80 V8 5.7L
1966	L6 4.8L	1981-77 V8 5.0L
Caballero		1981-72 L6 4.1L
1984-83	※1 V8 5.7L Diesel	1979-75 V8 6.6L
1983-78	V6 3.8L Optional	1979 V8 5.7L Gas
1982-81	V8 5.0L	1978-72 V8 5.7L
1982-80	V8 4.4L	

※1バッテリーを2個使用

Jimmy		P35, P3500 1 Ton – StepVan	
1976	V8 7.4L	1991–89	※1 L4 3.9L Diesel
1973	L6 4.8L	1989–84	L6 4.8L
1973	V8 7.4L	1986–84	V8 5.7L 7.4L
1972	V8 5.0L	1980–79	V8 7.4L
1971	V8 5.0L	1980–72	L6 4.8L
1970–68	V8 5.0L 5.7L	1977–74	V8 7.4L
1970	L6 4.1L	1977–72	V8 5.7L
1970	V8 5.0L 5.7L	1974–71	L6 4.1L
Jimmy S/T Series (Includes S15)		1973	V8 7.4L
1991–88	V6 4.3L	1971–70	V8 7.4L
1985–83	V6 2.8L Optional	1971–69	L6 4.8L
1984–83	L4 1.9L Optional 2.0L	1971	V8 5.7L
P15,P25,P1500,P2500 1/2Ton & 3/4Ton – StepVan		1970	L6 4.1L
1989–84	※1 V6 6.2L Diesel	1970	V8 5.7L
1986–85	L6 4.8L	1969–68	V8 5.0L
1986–85	V8 5.7L	1968–67	L6 4.8L
1984–83	L6 4.8L	1968	※1 L3 2.6L Diesel
1984–83	V8 5.7L	1967	L6 4.3L
1983–82	※1 V8 6.2L Diesel	1967	V8 4.6L
1980–72	L6 4.8L	1966	L6 4.1L
1979	V8 7.4L	R & V Pickup & Suburbans	
1975–71	V8 5.7L	1991–87	V8 5.7L Auxiliary
1974–71	L6 4.1L	1991–87	V8 5.7L ex.Auxiliary
1971–70	V8 7.4L	1991–87	V8 7.4L Auxiliary
1971	L6 4.8L	1991	※1 V8 6.2L Diesel
1970–68	L6 4.8L	1988–87	L6 4.8L
1970	L6 4.1L	1987	V6 4.3L Auxiliary
1970	V8 5.7L	1962–61	L6 4.4L
1969–68	V8 5.0L	1962–61	V8 5.0L
1969–68	L6 3.8L	S15 – Pickup	
1969–66	L6 4.1L	1986–85	L4 2.5L
1968	※1 L3 2.6L Diesel	1985–84	※1 L4 2.2L Diesel
1967–66	L6 4.8L	1985–84	V8 2.6L Optional
1967	V8 4.6L	1985–82	L4 1.9L Optional
1966	L6 3.2L	1984–83	L4 2.0L
1963	L6 3.8L	1983	V6 2.8L
P35, P3500 1 Ton – StepVan		Safari	
1999–97	V6 4.3L	2005–94	V6 4.3L ex.SEO
1999–97	V8 5.7L	2005–94	V6 4.3L SEO or Optional
1999–94	※1 V8 6.5L Diesel	1993–91	V6 4.3L
1999–89	V8 7.4L	1990–85	L4 2.5L Optional
1993–90	V6 4.3L	1990–85	V6 4.3L Optional
1993–89	V8 5.7L		
1993–84	※1 V8 6.2L Diesel		

※1バッテリーを2個使用

Savana (Includes 1500,2500,3500)		Yukon (Includes Denali,XL XL1500)	
2006	V6 4.3L	2006-01	V8 8.1L
2006	V8 4.8L 5.3L 6.0L	2006-00	V8 4.8L 5.3L 6.0L
2006	V8 6.6L Diesel	2006	V8 4.8L 5.3L 6.0L 8.1L Optional
2006	V6 4.3L ex.Supercharged	2005	V8 5.3L
2005-03	V8 4.8L ex.Supercharged	2000-94	V8 5.7L
2005-03	V8 5.3L ex.Supercharged	1999	※1 V8 6.5L Diesel
2005-03	V8 6.0L ex.Supercharged	1997-94	V8 6.5L Diesel
2002-96	V6 4.3L	1993-92	V8 5.7L Auxiliary
2002-96	V8 5.0L 5.7L		
2002-96	V8 6.5L Diesel		
2002-01	V8 8.1L		
2000-96	V8 7.4L		
Sierra C3			
2001	V8 6.0L 6.0L Optional		
Sierra Denali			
2006-02	V8 6.0L		
2006	V8 6.0L Optional		
2005-02	V8 6.0L Optional		
Sierra Pickup (Includes 1500,-HD,2500,-HD,3500)			
2006-99	V6 4.3L		
2006-99	V8 4.8L 5.3L 6.0L		
2006-01	※1 V8 6.6L Diesel		
2006-01	V8 8.1L		
2006	V8 4.3L 4.8L 5.3L 6.0L 8.1L All Optional		
2005-99	V6 4.3L 4.8L 5.3L All Optional		
2005-01	V8 6.0L 8.1L All Optional		
2004	V8 6.6L		
1993-91	L4 2.5L		
1993-91	V6 2.8L Optional		
Suburban			
1967-66	L6 4.1L		
1967-66	V8 5.0L		
1967-63	L6 3.8L		
1967	L6 4.8L		
1967	V8 5.4L		
1966	L6 4.8L		
1963	L4 2.5L		
Syclone			
1991	V6 4.3L		